






A627.H8.G Spare Parts




LT-A627.H8 Chassis frame

NO:	Code	Name	QTY	Remark
1	2.01.007.800067	A627.H8 chassis frame	1	
2	3.02.011.300080	A627 baseplate -B	1	
3	3.02.011.300069	A627 Side Sill-L	1	
4	3.02.011.300070	A627 Side Sill-R	1	
5	3.02.011.300085	A627 middle Side Sill -R	2	
6	3.02.011.300084	A627 middle Side Sill -L	2	
7	3.02.011.300081	Cover Plate	1	
8	2.02.007.010033	A627.2 floor plate	1	
9	2.01.007.800114	A627.6 battery holder	1	
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 steering system 1

NO:	Code	Name	QTY	Remark
1	3.01.004.070001	Steering Wheel	1	
2	3.01.004.070080	A627 Steering colum	1	
3	3.02.014.000038	Card Holder	1	
4	3.01.004.070018	Rod Steering	1	
5	3.01.003.060006	Screw	4	8x20
6	3.02.014.000255	A627 Column cover	2	595mm
7	3.01.003.100017	Nut	1	4
8	3.02.011.300051	A627 Steering switch wire cover	1	450mm
9	3.03.011.000025	Single arm combination switch	1	
10	3.03.011.000027	Single arm combination switch holder		
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 steering system 2

NO:	Code	Name	QTY	Remark
1	3.01.004.070011	Ball Joint	2	
2	3.02.014.000032	Dust Proof Rubber Boot	2	
3	3.01.004.070010	Inner Ball Joint	2	
4	3.01.004.070093	A627 Steering Gear Rack	1	22 mm
5	3.01.004.070013	Steering Box Housing	1	
6	3.01.004.900041	Universal Joint	1	
7	3.01.004.070012	Pinion Assy	1	
8	3.01.003.100016	Screw	2	12 mm
9	3.01.004.070072	Steering Assy 136	1	
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.2G front suspension 1

NO:	Code	Name	QTY	Remark
1	3.01.004.070021	Bush	4	Ø13x50mm
2	3.01.005.010008	arm	2	
3	3.01.004.070024	arm seal	4	Ø12x40.8
4	3.01.004.070023	arm shaft	2	
5	3.01.004.080004	front shock absorber up bush	2	
6	3.01.004.080002	front shock absorber/L	1	
7	3.01.004.080001	front shock absorber/R	1	
8	3.02.014.000081	front shock absorber up rubber	2	A-6-001
9	3.01.004.080017	A8 front spring	2	A-8-001
10	3.02.014.000082	Front Shock Absorber Down Rubber	2	45.5mm 74mm
11	3.02.014.000110	Knuckle Shaft Seal/big	4	
12	3.01.004.070022	Main Washer	2	
13	3.01.004.900019	Bearing	2	51103
14	3.01.004.070082	lifted knuckle/left	1	
15	3.01.004.070083	lifted knuckle/right	1	
16	3.01.004.090013	Bearing	2	MK120/20
17	3.01.004.090005	Bearing Base Seal	2	30x47x7
18	3.01.005.010009	Bearing Base	2	
19	3.01.003.070006	C Wheel Screw	8	(1/2)
20	3.01.003.100045	C Wheel Nut	8	(1/2)
21	3.01.004.090001	Bearing 6005	2	
22	3.01.004.090004	Bearing Cover	2	
23	3.01.004.090002	Bearing6204	2	
24	3.01.004.020011	aluminum rim LD-A0721270	2	
25	3.02.001.000021	Valve	2	TR414




LT-A627.2G rear suspension system

NO:	Code	Name	QTY	Remark
1	3.02.014.000053	Rear Shock Absorb Up Rubber Rim	2	44mm 55mm
2	3.01.004.080007	Rear Shock Absorb Bush	2	
3	3.01.004.080018	A11 Rear Spring	2	A-8-002
4	3.01.004.080005	Rear Shock Absorber	2	
5	3.02.014.000054	Rear Shock Absorb Low Rubber Rim	2	44mm 55mm
6	3.01.004.070021	Suspension Bush	1	φ13*50mm
7	2.01.007.800003	A627 Rear Balancing Pole	1	
8	2.01.007.800047	Transaxle Bend pipe assy	1	
9	3.02.014.000069	Shock Absorb Rubber	1	
10	2.03.001.000022	A11 Rear Shock Absorber Assy	2	
11	3.01.003.100015	Nut	4	10mm
12	3.01.003.060028	Screw	4	10x55
13	3.01.003.080022	Gasket	2	2.0x20x37
14	3.01.003.060037	Screw	2	12x70
15	3.01.003.100016	Nut	2	12mm
16	2.01.007.800048	rear shock absorb lifted stay	1	
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 DC motor system

NO:	Code	Name	QTY	Remark
1	3.03.007.000037	Speed Sensor	1	3.7KW ADC
2	3.03.007.000052	Magnetic Ring	1	3.7KW ADC
3	3.03.007.000012	Motor Cover	1	
4	3.01.004.090003	Bearing	1	6205
5	3.01.003.070014	Retainer Clip	1	
6	3.03.007.000005	ADC Motor Carbon Brush	4	3.7KW
7	3.01.006.000119	Carbon Brush Holder	1	ADC3.7KW
8	3.03.007.000013	Amature	1	ADC3.7KW
9	3.03.007.000011	Stator	1	ADC3.7KW
10	3.01.003.070015	Screw	3	1/4x50(6mm)
11	3.01.003.070016	Screw	1	8mm
12	3.03.007.000006	ADC DC Motor48v-3.7kw / Import	1	10
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 AC motor system

NO:	Code	Name	QTY	Remark
1	3.01.006.000393	Rear Cover	1	4KW
2	3.03.017.000077	Position Coder	1	4KW
3	3.01.006.900116	Pulse Wheel	1	4KW
4	3.01.004.900039	Bearing	2	6206ZZ
5	3.03.007.000083	Amature	1	4KW
6	3.03.007.000084	Stator	1	4KW
7	3.03.007.000086	Front Cover	1	4KW
8	3.01.006.000404	Motor Cable Borard	1	4KW
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 left brake

NO:	Code	Name	QTY	Remark
1	3.01.004.050049	E brake shoe	2	
2	4.03.001.000111	E brake shoe	1	
3	3.01.004.050002	Brake Assy/L	1	
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				



LT-A627.H8 right brake


NO:	Code	Name	QTY	Remark
1	3.01.004.050049	E brake shoe	2	
2	4.03.001.000111	Brake Repair Kit	1	
3	3.01.004.050001	Brake Assy/r	1	
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 brake system

NO:	Code	Name	QTY	Remark
1	3.01.004.050088	Brake Pedal	1	
2	3.03.005.000001	Accelerator Hall-a	1	Curtis controller
3	3.03.005.000009	Resistance Accelerator -3	1	Toyota controller
4	3.01.004.050033	Brake Pedal Panel	1	
5	3.02.014.200010	Brake Hook	1	
6	3.01.004.050040	Brake Pedal Support	1	
7	3.01.004.050048	Parking Pedal Spring	1	
8	2.01.004.010337	Parking Pedal	1	
9	2.01.004.010271	Brake Pedal Spring	1	
10	3.01.004.060004	Resistance Accelerator -3	1	
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				

LT-A627.H8 brake pull cable




NO:	Code	Name	QTY	Remark
1	3.01.004.040021	Rear Nail	2	8x22
2	3.01.004.040010	H8 Brake Pull Cable	1	
3	3.01.003.080004	Gasket	2	1.2x8x20
4	3.01.003.070036	Jump Ring	4	φ7
5	3.01.004.040022	Front Nail	1	10x25
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 front bumper

NO:	Code	Name	QTY	Remark
1	3.02.011.300065	A627 front bumper	1	
2	3.01.003.060006	screw	4	M8x20
3	2.01.007.800083	A627 front bumper base	1	
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 front body cover

NO:	Code	Name	QTY	Remark
1	3.02.011.300066	A627 Front Cover-b	1	
2	3.02.011.300038	A627 Electric Lock Cover	1	
3	3.02.011.300058	Front Support Decoration Cover/ L	1	
4	3.02.011.300059	Front Support Decoration Cover/ R	1	
5	3.02.011.300073	A627 Steering Column Trim Cover-b	1	
6	3.02.011.300067	A627 Front Dashboard-b	1	
7	3.02.011.300027	A627 Cup Base	1	
8	3.02.011.300075	A627 Ball Cabinet Cover/l	1	
9	3.02.011.300043	A627 Ball Cabinet Cover/r	1	
10	3.03.001.900023	Integrated Front Head Light/l	1	
11	3.03.001.900024	Integrated Front Head Light/r	1	
12	3.01.003.110003	Cross Recessed Flat Head Tapping Screws	6	M5x16
13	3.03.002.000006	Switch F/r	1	
14	3.03.011.000007	Power Indicator 48v	1	
15	3.03.002.000036	S14 Key Switch	1	
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				




LT-A627.H8 cargo box

NO:	Code	Name	QTY	Remark
1	5.01.002.300021	A627.H8 Standard configuration with Aluminum cargo box	1	
2	3.01.004.100011	Electrical Lift Rod	1	
3	3.02.014.000055	Rear Tire Decoration Cover/R	1	
4	3.02.014.000056	Rear Tire Decoration Cover/L	1	
5	2.02.001.020019	H2 Rear Cover/front	1	
6	2.02.001.020068	H8 Rear Cover/l	1	
7	2.02.001.020055	H8 Rear Cover/r	1	
8	3.02.005.020005	H2 Rear Cover/rear	1	
9	3.03.001.000009	Tail Light	2	
10	3.01.006.000008	Collar	2	φ 20x46
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				



LT-A627.H8 top roof and seat

NO:	Code	Name	QTY	Remark
1	2.02.001.110002	A627.H8 Standard configuration with Aluminum cargo box	1	
2	3.02.012.000040	windshield retain clip	2	730mm
3	3.02.012.000165	A627.2 windshield	1	
4	3.02.013.000049	A627 Side mirror/L	1	
5	3.02.013.000050	A627 Side mirror/R	1	
6	2.01.007.800072	A627.H windshield frame	2	
7	3.02.011.200006	A-U Roof Handle	2	
8	2.01.007.800073	A627.H rear support	1	
9	2.02.007.010023	A627 rear seat cushion	1	
10	3.02.011.300041	A627 front seat armrest	1	
11	2.02.007.010024	A627 rear seat back	1	
12	3.02.011.300028	A627 rear seat back cover	1	
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				





LT-A627.H8 DC system

NO:	Code	Name	QTY	Remark
1	3.02.014.000101	controller cover top	1	
2	3.02.014.000102	controller cover base1	2	
3	3.02.014.000103	controller cover base2	2	
4	3.03.003.000005	Curtis controller 1268-5403	1	
5	3.03.015.000001	48V sensor	1	ZJ200A
6	3.03.015.000003	48V sensor	1	ZJ50A
7	3.03.017.000012	fuse base	1	
8	3.03.017.000020	fuse 250A	1	
9	2.02.007.010030	Curtis heatsink board 1268	1	
10	3.03.016.000001	DC/DC convertor	1	48V/300W
11	3.03.010.000004	Buzzer(48V)	1	
12	3.03.017.000022	Resistance	1	
13	3.03.007.000006	ADC D motor 48V-3.7KW / Import		
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				

A627.H8 DC wire harness diagram


NO:	Code	Name	QTY	Remark
1	3.03.010.000004	Buzzer(48V)	4	36V
2	3.03.015.000003	48V DC Sensor	2	ZJ50A
3	3.03.015.000001	48V DC Sensor	4	ZJ200A
4	3.03.003.000005	Curtis Controller 12 68-5403	2	
5	3.03.017.000020	Fuse 250A	2	
6	3.03.007.000006	ADC DC Motor48v-3.7kw / Import	1	
7	3.03.001.000009	Tail Light	1	
8	3.03.016.000001	DC/DC Convertor	2	48V/300W
9	3.03.007.000037	Motor Speed Sensor	2	3.7KW
10	3.03.002.000008	Microswitch	2	
11	3.03.010.000007	Fanfare Horn	4	
12	3.03.011.000027	Single-arm Combination Switch Board	2	
13	3.03.011.000025	Single-arm Combination Switch	2	
14	3.03.012.000011	Relay	1	
15		Speed Meter	1	
16	3.03.011.000007	Power Indicator 48V	2	
17	3.03.002.000006	Switch F/R	2	
18	3.03.002.000036	S14 Key Switch	2	
19	3.03.017.900004	Fasher	8	
20	3.03.001.900024	Integrated Front Head Light/R	8	
21	3.03.005.000001	Accelerator Hall-A	2	
22	3.03.001.900023	Integrated Front Head Light/L	2	
23	3.03.002.000004	Two Switch(2 Level)	2	
24	3.01.004.100011	Electrical Lift Rod	2	
25	3.03.004.900062	A627.H Wiring Harness	2	





LT-A627.H8 AC spare parts

NO:	Code	Name	QTY	Remark
1	3.02.014.000101	Controller Cover Top	1	
2	3.02.014.000102	Controller Cover Base1	2	
3	3.02.014.000103	Controller Cover Base2	2	
4	3.03.016.000001	DC/DC Converter	1	48V/300W
5	3.03.017.000012	Fuse Base	2	
6	2.02.007.010031	Toyota Heatsink Board -A	1	
7	3.03.015.000001	48V Sensor	1	ZJ200A
8	3.03.003.000021	Toyota communication controller	1	48V/350A
9	3.03.017.000020	Fuse 250A	1	
10	3.03.010.000004	Buzzer(48V)	1	
11	3.03.007.000031	AC motor	1	4KW/33V AQHT4-4001B
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				



LT-A627.H8 battery system

NO:	Code	Name	QTY	Remark
1	3.03.009.000003	48V charger	1	
2	3.02.014.000102	Charger plug A	1	
3	3.03.009.000014	Charger receptacle A	1	
4	3.03.006.000030	Torch Battery 8V	6	
5	3.01.003.070013	Battery J-Bolt	2	6mm
6	3.02.014.000148	Battery retain clip E	2	
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				